



KWIKGAUGE BRICK TAPE

TAKE THE GUESS WORK OUT OF BRICKWORK



With KWIKGAUGE you will, in one measurement:

- Estimate brick quantities prior to & during building construction
- Chase bonds on concrete on footings & concrete slabs for setting up door jams & opening to suit brickwork
- Get correct placement of windows, sliding doors and door jams in frames prior to commencement of brickwork
- Set out brick gauge - no more pigs!
- Set out height of windows & doors
- Set out windows to suit bond
- Avoid unsightly 3/4 cuts
... and much more



Setting windows and doors to suit brickwork



Estimate brick quantities prior to & during building construction



Measuring gauge to drop off point



Establishing brick bond off a slab



With numbered gauges 84, 85, 86 & 87 you can set out gauge from drop off point and eaves to footings and slab to check how many courses and whether you need to open or close the gauge - no more pigs!



Set out window, door & arch bar heights from slab or footing for correct window and door position - no need to move them prior to the commencement of work!



Determining Brick sill quantity

**ALSO AVAILABLE
BLOCK TAPE**



Correctly position starter bars for both standard and H blocks. No need to bend starter bars! No more angry bricklayers!

