



Engine:

Part #	Item Code	Description	Qty
1	812734	MUFFLER COMPONENT	1
2	812662	MUFFLER GASKET	2
39	812739	STARTING MOTOR COMPONENT	1
42	812710	IGNITION COIL ASSEMBLY	1
43	812711	IGNITION COIL ASSEMBLY	1
44	812704	OIL ALARM	1
80	812657	CARBURETOR GASKET	3
83	812684	EXHAUST PIPE	1
89	812736	CARBURETOR ASSEMBLY	1
90	812663	AIR FILTER GASKET	1
93	812717	AIR FILTER ASSEMBLY	1
93A	812751	AIR FILTER ELEMENT	1
108	812859	OIL DIPSTICK ASSEMBLY	1
111	812696	OIL SENSOR	1




Frame:

Part #	Item Code	Description	Qty
1	812742	FRAME ASSEMBLY	1
3	812694	SHOCK ABSORBING BEARING (4PCS)	4
4	812693	SHOCK ABSORBING BEARING (2PCS)	2
5	812615	NUT	6
6	812583	LOCATING PIN LOCK CLAMP	2
8	812718	WHEEL ASSEMBLY	2
9	812707	AXLE	1
14	812588	SUPPORT RUBBER PAD	2
21	812678	RUBBER COVER FOR HANDLE	1
22	812709	HAND HANDLE TUBE ASSEMBLY	1
23	812659	CAP	2
24	812671	HANDLE RETAINING PIN	2
29	812732	AVR	1
44	812661	LOCATING PIN LOCK CLAMP	2




Alternator:

Part #	Item Code	Description	Qty
4	812723	ALTERNATOR SUPPORT	1
7	812692	CARBON BRUSH	1



Fuel Tank:

Part #	Item Code	Description	Qty
3	812854	FUEL TANK ASSEMBLY	1
8	812590	FUEL TANK CAP	1
9	812674	OIL FILTER	1
10	812688	OIL MARKER	1



Control Panel:

Part #	Item Code	Description	Qty
	812747	CONTROL PANEL ASSEMBLY	1

